



VICTORY  
4X4

# INTERIOR CARGO BASKET INSTRUCTIONS

## TOOLS NEEDED

- 5/32" allen
- Tape Measure
- Snips/Scissors
- Plastic pry tool

## HARDWARE

- 1/4-20 x 3/4" Button Head (Qty 29)
- 18-8 Stainless Washer (Qty 29)
- 1/4-20 Flange Nut (Qty 29)
- 18" Section of 5/16" Edge Trim

Please read the instructions below carefully before attempting to install.

1. Start by bolting the basket mounting brackets to each MOLLE panel using button head bolts, washers, and flange nuts. The basket may fit at several different heights, depending on vehicle model so you may need to measure to determine the best location for your basket. Here on the 100 Series, we installed them in the 4th row up from the bottom (5th Gen 4runner will install in the bottom row). The amount of bolts will also vary depending on vehicle model. Install bolts and flange nuts in all of the holes that align between the panel and the bracket (you may not use all of the bracket holes). Tighten them down with a 5/32" allen.



2. Now assemble the basket. To start, flip the two halves upside down and bolt them together at the bottom flange using button head bolts, washers, and flange nuts. When they are all installed, tighten them down with the same 5/32" allen.



- 3.** Flip the basket back over to install the tie-in brackets. Place the brackets on the outside of the basket and run the button head bolts through from the inside (this way the bolt ends don't protrude into the cargo area). Install all four bolts, washers, and flange nuts on each side loosely and then tighten them down.



- 4.** Install the supplied edge trim in each corner. Cut it into four 3" pieces. Use a non-marring plastic pry tool to open up the corner slightly and press the edge trim onto the side panel edge.



5. Carefully slide the basket onto the two side brackets, making sure you don't scratch the plastic interior trim near the hatch. On the 100 Series we are able to slide it straight in the back hatch. In other vehicles (i.e. 4Runner) you may need to fold the rear seats down and bring the basket in through the rear passenger door and slide it onto the brackets from the front.



6. Bolt the basket to the brackets, dropping the bolts/washers through from the top with flange nuts on the underside. Start them all loosely first and then tighten them up with a 5/32" allen.



7. Thats it. Enjoy your new Interior Cargo Basket!

