



VICTORY
4X4

GX470 HATCH MOLLE PANEL INSTRUCTIONS

TOOLS NEEDED

- phillips screwdriver
- 1/8 drill bit or pick
- Razor blade

HARDWARE

- 8 screws
- 8 spacers

Please read the instructions below carefully before attempting to install.

1. Cut out the old netting with a razor blade (optional). Pull the net outward and cut right at the edges.



2. Align the MOLLE panel to the existing netting trim and mark one hole. The panel is directional, so make sure the bottom radius' match the trim piece on the tailgate (larger radius will be closest to the rear, with the hatch open).



3. Remove the panel and start one screw in the location that you marked. Once the hole is started, remove the screw and then reinstall it through the panel.



4. Align the panel and start the rest of the screws.



5. Once all of the screws are started, you have two options. You can fully snug them all and you are done. You can also remove them, install the provided spacers behind the panel and reinstall the screws. Either way will work, using the spacers will allow you to strap gear all the way around the edges of the panel as well.



6. Enjoy your new Hatch MOLLE Panel!

4. Do not overtighten the screws but make sure they are snug. When you have completed 1 side, repeat the same steps on the other side. Look at the pictures below to make sure your panel is installed just like ours.

4th Gen 4Runner



5th Gen 4Runner



2nd Gen Tacoma



3rd Gen Tacoma



Tundra

