



VICTORY  
4X4

# TACOMA HOOD ANTENNA MOUNT INSTALLATION INSTRUCTIONS

## TOOLS NEEDED

- 12mm socket
- Channel lock pliers

Please read the instructions below carefully before attempting to install.

1. Remove the hood bolts on the passenger side. Be sure to hold the corner of the hood to prevent it from falling into the windshield. We recommend using a sharpie to mark where the bracket goes. Use a 12mm socket and remove the two bolts so we can install the bracket.



2. Line the bracket up with the hinge. Make sure your hinge is lined up with the marks we made with a sharpie. Using a 12mm socket, reinstall the two factory bolts to secure the bracket to the hood.



3. After you get the mount installed, push up on the bottom of the bracket to push the threads through the hole. Install the small rubber washer with the brass nut on top. You can use channellocks to tighten the brass nut but make sure you don't overtighten.



You are now finished with the install! Enjoy your new Hood Antenna Mount!