



VICTORY
4X4

CENTER CONSOLE MOLLE PANEL INSTRUCTIONS

TOOLS NEEDED

- Phillips Screwdriver
- 1/8" Drill Bit or Pick

HARDWARE

- 8 screws
- 8 spacers

Please read the instructions below carefully before attempting to install.

1. Move your seat all the way back to make as much room as possible before installing the panel. Line up the panel so its flush with the center console. Mark the screw holes with a pick or a sharpie.



2. Use a drill bit or a pick to puncture a hole into the plastic but make sure the pick is smaller than the screw or use a 1/8" drill bit. Be sure you only drill deep enough to get the screws started.



3. Install the panel using a Phillips screwdriver. Use 1 screw and 1 spacer per hole. Not every panel will use 4 screws and spacers, this will vary by vehicle.

4th Gen 4Runner

- 8 screws (4 per side)
- 8 spacers (4 per side)

5th Gen 4Runner

- 8 screws (4 per side)
- 6 spacers (3 per side)
- Do not install a spacer on the top front screw.

2nd Gen Tacoma

- 8 screws (4 per side)
- 4 spacers (2 per side)
- Do not install spacers on the back 2 screws.

3rd Gen Tacoma

- 6 screws (3 per side)
- 6 spacers (3 per side)

Tundra

- 8 screws (4 per side)
- 8 spacers (4 per side)

Land Cruiser

- 8 screws (4 per side)
- 4 spacers (2 per side on the rear two holes)

Land Cruiser 200 Series

- 8 screws (4 per side)
- 8 spacers (4 per side)


GX470

- 8 screws (4 per side)
- 8 spacers (4 per side)

GX460

- 8 screws (4 per side)
- 7 spacers (see locations below)

S | SHORT SPACER
L | LONG SPACER
∅ | NO SPACER



GX460

4. Do not over-tighten the screws but make sure they are snug. When you have completed 1 side, repeat the same steps on the other side. Look at the pictures below to make sure your panel is installed just like ours.

4th Gen 4Runner



5th Gen 4Runner



2nd Gen Tacoma



3rd Gen Tacoma



Tundra



Land Cruiser 100 Series



Land Cruiser 200 Series

