




VICTORY 4X4

3RD GEN TUNDRA BEDSIDE MOLLE PANEL

INSTALL INSTRUCTIONS




Please read the mounting instructions below carefully before attempting to install.

Be sure to check out the install video on the product page, if available.

Thank you for purchasing from Victory 4x4! Checkout our website, victory4x4.com for other great off-road products. Be sure to rate and review our product online. If you have any questions or are missing parts, please don't hesitate to call us at 269-459-8447!


INCLUDED HARDWARE

7x




5/16"-18 X 5/8"
Button Head

9x




5/16"-18
Serr. Flange Nut

2x



5/16"-18 X 1 1/4"
Button Head


2x




Off-White 3/4" x 1/4"
Spacer for 5/16" Bolt

INCLUDED PARTS


1x



1x




4x






INSTALLATION

- 1** Start by connecting both panels using the 5/16"-18 X 5/8" button head bolts and 5/16"-18 serr. flange nuts. It doesn't matter which panel goes on top, just make sure to have the smaller of the two panels arranged and oriented like the image below. This is the best time to attach any mounts you will be using to the panel because it can be difficult to access the back of it once it is installed.




- 2** Next, remove the trail rail using a T30 torx from whichever side you are installing the panel on. Then, using the factory hardware, loosely reinstall it making sure to put a mounting bracket between it and the bed of the truck on every hole but the middle. Make sure when tightening, that the brackets are snug against the rail.




INSTALLATION

- 3** Next, after you have your panels assembled and brackets in place, then start to loosely bolt your panel into the brackets like arranged and oriented below with the provided 5/16" button head bolts and flange nuts.



INSTALLATION

- 4** Once the panel is loosely installed get it oriented where it's level and parallel with the trail rail and then tighten everything down. Once it is positioned how you like it, you then need to drill two holes using a 5/16" drill bit using the holes shown below as a guide.



- 5** After the holes are drilled, place the two provided spacers behind the panel in line with the new holes. Then place the two provided longer 5/16" bolts through the panel and spacers and place the provided 5/16" flange nuts on the backside of the bolts up through the backside and tighten down.

