



VICTORY
4X4

4RUNNER 5TH GEN BLITZ SLIDER INSTALLATION INSTRUCTIONS

TOOLS NEEDED

- Pry tool
- Ratchet
- 12 & 13 mm & 9/16" socket
- 5/16" drill bit
- 5/16" allen
- 1/2" wrench
- 3mm allen
- 5/16" socket

HARDWARE

- 8mm-1.25 Hex head Flange Bolt qty. 22
- 3/8 Hex Head Self Threading Screws qty. 3
- 5/16-18 x 3/8" Hex Head Bolt qty. 8
- 1/4-20 x 3/4" Button Head qty. 12
- 1/4-20 Flange Nut qty. 12
- 1/2-13 x 1" Button Head qty. 16
- 1/2-13 Flange Nut qty. 16

****2010- 2013 and 2010+ Limited models will need to remove or trim the rocker trim. You have the option to remove the trim and replace it with the 2014+ rocker trim.****

Toyota Part Numbers:

75805-35130
75806-35100
75875-35010
75858-35010

Please read the instructions below carefully before attempting to install.

1. Bolt on the corner logo plates using the small button head bolts and flange nuts.



2. Now bolt the legs onto the slider. The outer portion of the sliders are symmetrical. The only difference between sides will be how the legs are positioned. Both legs will be bolted in the front-most set of holes. (closest to the front of the vehicle). There will also be an arrow cut in the mounting plate of each leg pointing toward the front of the vehicle. Once you have them positioned, install them using the provide button-head bolts and flange nuts. Do not fully tighten them yet.



Driver's side shown.

3. Install the LED lights using the provided button head bolts, washers, and lock nuts. Make sure the lights are centered in the hole and tighten them down using a 3mm allen and a 5/16" socket or wrench



4. Remove the plastic clips along the frame



5. Remove the three bolts holding the gas tank skid in place. Then remove the bolt holding up the brake line and any other lines (KDSS if you have it).



Driver side.

6. Use a jack to raise the slider into place. Make sure the slider is slid between the frame and the gas tank skid as shown in the picture below. (and between the frame and KDSS if you have it)



7. With your slider in place, begin loosely installing bolts into the mounting holes. Once you get all of the bolts installed, tighten the bottom bolts (Image 2) to bring the slider against the frame before tightening the other bolts. Once the bottom bolts are tight, go back and tighten the rest of the bolts. If you have KDSS, you will bolt it back on over the slider mounting plate.



Repeat the same steps on the passenger side.

8. Now that you have the slider in place, make sure the outer portion of the slider is positioned correctly (centered left to right and level). Once you have it positioned tighten down the eight 1/2" button head bolts. It may be easier to remove the slider to do so, but if you have a 5/16" bit for a socket with an extension, you may be able to tighten it in place.
9. On the passenger side, you will need to drill two holes to 5/16" if you are using them as rock sliders.



10. Once the two holes are drilled, use two 3/8" self-tapping bolts with a 9/16" wrench to secure the bolts. (do not over tighten them, just until they are snug)



11. You will find one bolt hole on the passenger side that is smaller than the others. Once you find the smaller hole use a self-tapping bolt to secure it.



12. That's it! Wire your lights however you prefer and enjoy your new sliders!

