



VICTORY  
4X4

# **GX460 REAR WINDOW MOLLE INSTALLATION INSTRUCTIONS**

## **TOOLS NEEDED**

- Phillips Screwdriver
- 5/32 Allen
- Flathead Screwdriver
- 10mm Socket

## **HARDWARE**


- M6x1mm x 55mm Button Head qty. 2
- 1 1/2" White Nylon Spacer qty. 2
- 1/4-20 x 3/4" Button Head qty. 4
- 1/4-20 Flange Nut qty. 4
- M6 x 25mm Stainless Button Head qty. 2

**Please read the instructions below carefully before attempting to install.**

1. Remove the cargo net hook.




2. Remove the phillips head screw.



3. Remove the seat belt clip. Press in the tabs holding it in with a flat head screwdriver



4. Remove the small panel below the window. Then remove the phillips head screw that the panel was covering up.




5. Use the longer bolt we provide, a spacer, and the C-shaped bracket and loosely install it into the screw hole that we removed in step 4.




6. Remove the right side bolt from the handle. Squeeze the side of the handle and pull back on the plastic cover to expose the 10mm bolt.



7. Install the rear and top brackets to the panel using the small button head bolts and a flange nut. 1 bolt goes in the rear bracket and 2 in the top bracket.





8. Now we can install the panel. Start by hanging the panel from the top bracket. Use the 10mm bolt we removed earlier and secure it to the handle.




9. Next we will install the rear bracket. Use a spacer and the long button head bolt. Make sure the seat belt is in front of the panel and not behind it.



10. Tighten the C bracket behind the panel using a 5/32 allen. Once the bracket is tight, you can secure the panel to the bracket using a button head bolt and flange nut.



- 11.** Tighten the C bracket behind the panel using a 5/32 allen. Once the bracket is tight, you can secure the panel to the bracket using a button head bolt and flange nut.



- 12.** Reinstall the seat belt clip and cargo net hook to the panel. Go back and tighten everything down and you will be finished with the install.

