



GX 460 & 470 REAR WINDOW MOLLE INSTALLATION INSTRUCTIONS

TOOLS NEEDED

- Phillips Screwdriver
- 5/32" Allen
- Flathead Screwdriver
- 10mm Socket
- 14mm Socket

HARDWARE

GX460

- M6x1mm x 55mm Button Head qty. 2
- 1 1/2" White Nylon Spacer qty. 2
- 1/4-20 x 3/4" Button Head qty. 4
- 1/4-20 Flange Nut qty. 4
- M6 x 25mm Stainless Button Head qty. 2

GX470

- 1/4-20 x 1" Button Head qty. 4
- 1/4-20 Flange Nut qty. 4
- M6x1mm x 55mm Button Head qty. 2
- 5/8" OD x 1.5" Plastic Spacer
- External-Tooth Lock Washer for 5/16" Screw Size
- M6 x 1mm x 40mm Hex Head
- 5/16"-18 Threaded Hex Coupler
- 1/4" Flat Washer
- M6 Nutsert
- 23/64" Drill Bit

Please read the instructions below carefully before attempting to install.

GX 460

1. Remove the cargo net hook.



2. Remove the phillips head screw.



3. Remove the seat belt clip. Press in the tabs holding it in with a flat head screwdriver



4. Remove the small panel below the window. Then remove the phillips head screw that the panel was covering up.




5. Use the longer bolt we provide, a spacer, and the C-shaped bracket and loosely install it into the screw hole that we removed in step 4.




6. Remove the right side bolt from the handle. Squeeze the side of the handle and pull back on the plastic cover to expose the 10mm bolt.



7. Install the rear and top brackets to the panel using the small button head bolts and a flange nut. 1 bolt goes in the rear bracket and 2 in the top bracket.





8. Now we can install the panel. Start by hanging the panel from the top bracket. Use the 10mm bolt we removed earlier and secure it to the handle.




9. Next we will install the rear bracket. Use a spacer and the long button head bolt. Make sure the seat belt is in front of the panel and not behind it.



10. Tighten the C bracket behind the panel using a 5/32 allen. Once the bracket is tight, you can secure the panel to the bracket using a button head bolt and flange nut.



- 11.** Tighten the C bracket behind the panel using a 5/32 allen. Once the bracket is tight, you can secure the panel to the bracket using a button head bolt and flange nut.



- 12.** Reinstall the seat belt clip and cargo net hook to the panel. Go back and tighten everything down and you will be finished with the install.




GX 470

We will be removing the interior trim panel to add nutserts behind it to mount the MOLLE panel to.

1. Remove the cargo net hook from the threaded stud.



2. Remove the hatch sill trim using a phillips head screwdriver. Once the screws are removed, it will just be held in with clips and can be popped out.



3. Remove the trim panels just inside the rear door.



4. Remove anything else attached to the rear interior panel, power outlet, seatbelt bolts, etc.



5. Now pop the interior panel out. You will need to pry the plastic up past the third row seat mechanism with a screw driver or pry tool so it can slide up and over.



6. Remove the two white plastic clips from the back of the panel. Use those clip locations to drill through the panel with a pilot bit. This will mark the hole locations on the front for the nutserts.



7. Open up the two holes that the white clips clipped into with the included 24/64" drill bit. Install two nutserts into the metal.



8. Now reinstall all of the interior trim.

9. Open up the pilot holes (in the plastic only) to 1/2".



- 10.** Install the spacers, bolts, and lower brackets through the plastic and into the nutserts as shown.



- 11.** Remove the grab handle by prying off the caps and removing the bolts using a 10mm socket.



- 12.** Reinstall the grab handle with the upper bracket behind it.



- 13.** Install the MOLLE Panel to the brackets using button head bolts and flange nuts. Make sure all of your bolts are tight and you are done with the install!!

