



VICTORY
4X4

TUNDRA BED STIFFENERS INSTALLATION INSTRUCTIONS

TOOLS NEEDED

- T-55 torx bit
- T-30 torx bit
- 5/8" socket
- small drill bit
- step bit or 7/16" drill bit
- spray paint

HARDWARE

- 7/16-14 flange nut qty. 6
- 7/16 flat washer qty. 6
- 7/16-14X1" hex cap qty. 6

Please read the instructions below carefully before attempting to install.


1. There will be a left side and right side bracket when you open the kit. To determine which side the brackets mount to, make sure the bend is toward the inside of the truck. Using a T-55 torx, remove the body mount as shown in the picture below.



2. After you remove the bolt, put the bracket in place. Make sure it sits at a 90 degree angle and is flush with the side of the truck. Mark the bolt holes with a sharpie to determine where we will drill.




3. Use a small drill bit and begin drilling the holes that we marked in step 2. Once you have the holes drilled, use a step bit to make the holes bigger. We are using 7/16" hardware so you will need to drill up to 7/16".



4. Use spray paint and cover the drill holes.



5. Using a T-30 torx bit, remove the two bolts holding the brake light in place. Once the brake light is loose, pull it away from the truck then pull straight back.



6. After you remove the brake light, put the bracket in place. Loosely install a 7/16" bolt and washer with a flange nut on the other end. For the bottom bolt you will need to reach under the truck and get the bolt started. We are using flange nuts so you will only need to tighten the bolt from one side.



7. Secure the body mount we removed earlier using a T-55 torx bit.



8. Tighten the other 3 bolts using a 5/8" socket.



After you reinstall the brake light, repeat the same steps on the other side and you're finished with the install!